

How can I switch between maps?

You can switch between different oblique photos to view your solar layout from different cardinal or ordinal directions.

You will either have a selection of cardinal (North, South, East and West) photos or ordinal (North-East, South-West, South-East, North-West) photos depends on the orientation the survey flight took.



You can only see these oblique photos if your Nearmap on OpenSolar subscription includes Nearmap Obliques,

You can also switch your vertical base layer map to an older survey date. Find out how to do this in this FAQ: [How can I view historical Nearmap imagery in Nearmap on OpenSolar?](#)